




AD-48BDD Instruction Manual




FAGOR UNDERCOUNTER DISHWASHER WITH DRAIN PUMP AND DETERGENT DISPENSER

**Fagor Australasia Pty Ltd
7 Boola Place
Dee Why
NSW 2099
Phone: 02 9984 7533
Fax: 02 9984 7544
Email: info@fagor.com.au**

1. POSITIONING

1.1 For the machine to work properly, you must ensure that it is level. Four threaded bolts (legs) are supplied with your machine. These should be fitted to the underside of the machine and adjusted to level the machine, as shown in Figure 1.

Figure 1



2. INSTALLATION

2.1 Connect the mains to the water supply, as shown in Figures 2 and 3. The machine should be connected to a hot water supply of above 50°C but no more than 60°C to allow the machine to operate efficiently. Inlet operating pressure is 400 kPa and maximum inlet supply temperature is 60 °C

2.2 If the pressure is more than 70 PSI, a pressure limiting valve should be fitted.

Figure 2






Figure 3




PLUMBER

- S = Stopcock
- F = Filter
- H = Fagor supplied hose and backflow prevention device
- E = Electrovalve
- B = Electropump
- C = Drain collector
- D = Drain hose 25mm in diameter and must be installed in accordance with AS/NZS3500.2 (drainage) by means of coupled connection to a DN40 or larger pipe

NOTE: must be installed in accordance with AS/NZS3500.1 (water service supply) including installation of the supplied backflow prevention device.

2.3 Dynamic pressure during rinse is $4 \pm 5 \text{ Kg/cm}^2$. If the pressure is less than 2 kg/cm^2 (28 PSI), an electrical pressure pump should be installed, as shown in Figure 4.

Figure 4




- S = Stopcock
- F = Filter
- H = Fagor supplied hose and backflow prevention device
- E = Electrovalve
- B = Electropump
- C = Drain collector
- D = Drain hose

2.4 When the water hardness level is above 10° dF , a water softener should be installed.

2.5 A stopcock should be fitted below the machine's water intake.


2.6 Fix the drain hose as shown in Figure 5 and fit a siphon pipe to prevent bad smells. Please note the maximum height of the drain hose indicated on Figure 5. Do not extend the length of the drain hose supplied with your machine.

Figure 5




PLUMBER

C=Drain collector
D=Drain hose
F =Filter



- 2.7 Connect the electrical connections, referring to Figures 2, 6 and 7.
- 2.8 For access to the connection strip (R), remove the cover (T) and the rear panel (P).
- 2.9 Fix the sheathed cable to (E), leaving enough cable to remove the electrical panel from the front.
- 2.10 Connect the strip as shown in Figure 6.
- 2.11 Fit a general switch (I) independent of the appliance with a distance between contact equal to or more than 3mm.
- 2.12 The machine must be earthed.

Figure 6



ELECTRICIAN and PLUMBER

am/ve=yellow/green
 m= brown
 r= red
 n=black

Figure 7




Figure 8: Technical Specifications of AD-48 BDD

Model	Water inlet pressure	Supply Voltage	Tank Heating Element	Boiler Heating Element	Max. power used	Basket size	Cycle duration	Tank capacity	Rinse water consumed	Net Weight
AD 48 BDD	(400+500 kPa) (4+5 Kg/cm ²) (5-70 PSI)	230V – 1 + N; 15 Amp; 1 Phase	2.8 KW	2.8 KW	3.45 KW	500x500 mm	60", 90", 180"	25 litres	2.7 litres/rinse	60 KG


3. USING YOUR AD-48 BDD UNDERCOUNTER DISHWASHER

3.1 Put the clear hose (located at the back of the machine), into a bottle of liquid, non-foaming detergent. Make sure that the filter on the end of the pipe is fully submerged and the pipe is not kinked.

3.2 Put the blue hose (located at the back of the machine), into a bottle of rinse aid. Make sure that the filter on the ends of the pipe is fully submerged and the pipe is not kinked.


3.3 Prepare crockery for washing by removing large bits of food before loading the crockery into the baskets. Glassware should be washed first. Plates should not be stacked on top of each other (see Figure 9). Cups and glasses should be washed upside down. Cutlery should be washed in the yellow cutlery baskets with handles at the bottom; each yellow basket should contain a mixture of spoons, forks and knives for optimum washing conditions. The cutlery holders should be put into one of the baskets.

Figure 9



3.4 Load the machine with a basket of dirty dishes/cutlery. Close the door and press the switch button (1 on Figure 10) to turn machine on. Pilot light (2) will come on and the boiler and wash tank will begin to fill up with water and heat up.

Figure 10



PLUMBER

3.5 Wait for water to heat up to required temperature. The thermometer (9) indicates the rinse temperature and the (10) wash temperature. The machine is ready when the thermometer (9) indicates 85-90°C and the thermometer (10) 55-60°C. The dishwasher is fitted with a thermostop to ensure a minimum rinse temperature of 85°C. **The temperature of the incoming water should be 50°C or more. Colder water may affect the machine's performance.**

3.6 Press P1, P2 or P3 button to select the require length of the wash (60", 90" or 180" respectively). The appropriate LED (4,6 & 8 on Figure 10) will light up.

3.7 When the cycle has finished, the LED will go off. The door can be opened and the basket removed. Another basket of crockery can be inserted and button P1, P2 or P3 pressed for another wash cycle to start. Never place a basket of washed dishes on top of the machine; water could drip from the basket and damage the machine's electrical components.


3.8 The dishwasher drains automatically in each cycle. At the end of each day or service, or as required, the dishwasher should be completely drained. See details below:


Make sure the machine is turned on.


1- Remove bottom right hand tray from the interior of the machine.




2- Remove the upstand (drain plug) by pulling it up from inside the filter (See photo and 'A' in Fig. 5).



3- Leave the door open and press the button P1  for 5 seconds until the green light flashes.



3- You will hear the pump start to work and see the drain out. When the pump stops making a noise and the water is drained out, remove the 4 tray filters and the suction filter ('F' on Fig. 5) by turning it anti-clockwise and pulling out. Use soapy water to clean the trays and filter, ensuring that all particles are removed.



4- Replace trays, suction filter and drain plug in machine. The machine is now ready to be re-used or turned off, as appropriate.

4.- MAINTENANCE

4.1 Check the detergent and rinse liquid containers on a daily basis to ensure levels are sufficient and the filters on the ends of the pipes are fully submerged. Check pipes leading from the containers for kinks.

4.2 Everyday, clean the filter-trays in the bottom of the machine and the suction filter (F on figure 5). To do this, remove the anti-overflow device (drain plug) in the middle of the suction filter, turn (F) anticlockwise and lift it up. Use soapy water for cleaning, not abrasive detergents. Never use jets of water to clean the outside of the machine.

4.3 Check that all parts are securely fixed, in particular that the screws on the wash and rinse arms have not worked loose.

4.4 If the machine is not going to be used for a long time, cover its surfaces with a coating of petroleum jelly.

ELECTRICAL AND MECHANICAL PROBLEMS – (TROUBLESHOOTING)

The following should be checked before calling for technical service:

- 5.1 If the machine has no power, check if it is plugged in to the power supply and that the voltage coincides with that required by the machine.
- 5.2 If the machine has no power, check if the power cord is damaged, in which case it should be replaced by the manufacturer or by its aftermarket service or by other qualified personnel in order to prevent hazards.
- 5.3 If the water connection or the start up take too long check the water supply is working at the required temperature and that the drain plug has been inserted.
- 5.4 If the machine is not rinsing or washing properly, check that the arms rotate properly and the nozzles are not blocked. To remove the rinse arm, unscrew the thumb screw in the central support (using a coin). Wash the rinse arm in soapy water and reposition. Tighten the screw.
- 5.5 If the machine is not washing or rinsing properly, check the levels of rinse aid and detergent and check that the supply pipes are not kinked and do not have an air bubble blocking them.

5.6 After sales service:

Fagor Australasia Pty. Ltd., 7 Boola Place, Dee Why, NSW.

Tel. 02 9984 7533

Email: info@fagor.com.au

6. INFORMATION FOR TECHNICIANS

6.1 CONFIGURATION OF THE DIPS


FAGOR ELECTRIC ADVANCE MODEL	DIP1	DIP2	DIP3	DIP4	CYCLE TIMES (seconds)
AD 48 BDD	OFF	OFF	ON	OFF	P1= 60 / P2=90 / P3=180

DIP1 = ON, when the door is closed, the dishwasher starts.

DIP1= OFF, when the door is closed, the dishwasher continues washing *if the cycle has not finished.*


DIP2 = OFF

DIP1 + DIP3 , with the different possible combinations, we programme the cycle times.



6.2 ERROR DIAGNOSIS.

Faults are diagnosed with impulse trains from the ON/OFF LED. The trains are formed by "x" impulses lasting 0.5 seconds. (ON) and a wait of 2 seconds, as shown in the following figure:



Example of a 2-impulse train. In the event of an impulse, the ON/OFF Led lights up.

1. ERROR: OPEN DOOR

This is indicated by a one-impulse train. That is, the ON/OFF LED lights up for 0.5 seconds and then remains unlit for 2 seconds before lighting up again. This continues as long as the door is open and the selected cycle is unfinished.

2. TANK FILL ERROR.

This is indicated by a two-impulse train. That is, the ON/OFF LED lights up twice for 0.5 seconds each time and then remains unlit for 2 seconds, then lighting up again twice. This continues while the water in the tank does not reach the correct level in the specified time.

3. TANK DRAINAGE ERROR.

This is indicated by a three-impulse train. That is, the ON/OFF LED lights up three times for 0.5 seconds each time and then remains unlit for 2 seconds, then lighting up again three times. This continues while the drainage pump does not drain the water in the tank to the correct level in the specified time.

4. BOILER HEATING ERROR.

This is indicated by a four-impulse train. That is, the ON/OFF LED lights up four times for 0.5 seconds each time and then remains unlit for 2 seconds, then lighting up again four times. This continues while the water in the boiler does not reach the correct temperature in the specified time.

5. TANK HEATING ERROR.

This is indicated by a five-impulse train. That is, the ON/OFF LED lights up five times for 0.5 seconds each time and then remains unlit for 2 seconds, then lighting up again five times. This continues while the water in the tank does not reach the correct temperature in the specified time.

NOTE.- THE FINAL HOLDER OF THE CONTAINER WASTE IS RESPONSIBLE FOR ITS MANAGEMENT.



The use of the WEEE symbol indicates that this product may not be treated as household waste.

By ensuring this product is disposed of correctly, you will help protect the environment.

For more detailed information about the recycling of this product, please contact your local authority, your household waste disposal service provider or the shop where you purchased the product.

FAGOR 